




PORTABLE STEEL SCAFFOLD ADJUSTABLE HEIGHT

INSTALLATION INSTRUCTIONS

SUITABLE FOR INTERIOR & EXTERIOR DOMESTIC APPLICATION

Assembled size: **181cm** H x 187cm W x 74cm D

Maximum working height: 1.25m



224kg

LOAD CAPACITY

3.25m

REACH HEIGHT

PORTABLE STEEL SCAFFOLD ADJUSTABLE HEIGHT

SUITABLE FOR INTERIOR & EXTERIOR DOMESTIC APPLICATION

Assembled size: **181cm** H x 187cm W x 74cm D

Maximum working height: 1.25m


Load capacity 224kg Reach height 3.25m

EASY ASSEMBLY – Spring-loaded locking mechanism

EASY TRANSPORT – Lockable castors

EASY ADJUSTMENT – Adjust platform height and ends separately

NO	DESCRIPTION	QUANTITY
1	Horizontal Frame	2
2	Adjustable Square Pole	2
3	Plywood	1
4	Pin	8
5	5" Swivel Wheels with Brake	4



ASSEMBLY:

1. Insert casters in side frame's lower extremity. Secure casters with locking pins. Lock the casters by firmly depressing the top tab of the caster.
2. While maintaining the brace locking mechanism pulled, insert the braces onto the frame sides at desired height.
3. Ensure that the locking stems are properly engaged in side frames.
4. Secure the brace using the locking pins.
5. Install the platform on the braces.
6. Turn the platform security latches toward the inside.

DIRECTIONS FOR USE:

- DO NOT use a moving scaffold.
- DO NOT move scaffold from on top.
- DO NOT use damaged or deteriorated equipment.
- DO NOT use unstable objects such as boxes, bricks, concrete blocks, etc. under scaffold legs.
- Be certain work platform is fully seated within channel before use.
- Be certain all locks attaching side rails to end frames are fully engaged before accessing platform.
- Inspect scaffold daily and make sure each part can be used and is not worn, damaged or missing.
- When accessing platform, climb over the top of end frame ladder.

DO NOT SWING AROUND SIDE OF END FRAME. Swinging around side of the end frame will cause scaffolding to tip over resulting in serious injury or death.

- All casters need to be locked to prevent caster rotation and scaffolding movement.
- DO NOT work on scaffolds if your physical condition is such that you feel dizzy or unsteady in any way.
- DO NOT work under the influence of alcohol or illegal drugs.
- DO NOT attempt to move a rolling scaffold without sufficient help – watch out for holes in floor and overhead obstructions – stabilise against tipping.
- DO NOT jump onto planks or platforms.
- DO NOT use ladders or makeshift devices to increase working height of a scaffold. Do not plank guard rails to increase the height of a scaffold.
- Climb in access areas only and use both hands.
- DO NOT overreach. Keep proper footing and balance at all times.
- DO NOT store scaffolding outside.



Made to Australian & New Zealand standards AS/NZS 1576.1:2010

MADE IN CHINA CODE: 0860882

www.rhinoladders.com.au

www.rhinoladders.co.nz